

Local Power Supply

230 Volt Single Phase, 60Hz

Additional Power

Situated Upstage Left	32A X 2	16A X 2	(Legrand Type)
Situated Upstage Right	32A X 2	16A X 2	(Legrand Type)
Situated Stage Right	32A X 1	16A X 1	(Legrand Type)

Control Console

Main Console	DIGICO	SD10T (software version 16.0.1619)	2ea (main) (redundant) (optocore)	Fixed_(STAGE)	SD-Rack(1.24)_(48in24out)_Dante_Card
					AES/EBU_16out => Galileo AES/EBU
				Fixed_(STAGE)	SD-Rack(1.23)_(48in16out)
					AES/EBU_8out / Aviom D-16_Card
				Fixed_(FOH)	SD-Rack(1.11)_Mini_(24in/8out)

Speaker System

Main Left	(Fixed)	L-ACOUSTICS	L2 / LD2	1ea/1ea	Fixed_(Room)	LA7.16 / 4ea
Main Right	(Fixed)		L2 / LD2	1ea/1ea		
Center (1F/2F)	(Fixed)		KIVA II	6ea/4ea	Fixed_(Room)	LA4X / 1ea
Center Side Fill	(Fixed)		X12	2ea	Fixed_(Room)	LA4X / 1ea
Sub Woofer	(Fixed)		KS28	4ea	Fixed_(Room)	LA12X / 1ea
Inner Fill (1F/2F)	(Fixed)		X8	4ea/2ea	Fixed_(Room)	LA4X / 1ea
Under Balcony	(Fixed)		5XT	8ea	Fixed_(FOH)	LA4X / 1ea
Front Fill			5XT	10ea	Fixed_(Room)	LA4X / 1ea
Monitor Speaker			MTD112	10ea		LA4 / with bracket 8ea
			8XT	3ea		LA4 / with bracket 3ea
Surround Speaker	(Fixed)	JBL	8330A	24ea	Fixed_(Room)	QSC CX254
Speaker		MEYER	MM-4XP	8ea		MPS-488 / 2ea / with bracket 10ea
			UPA-1P	4ea		with bracket YOKE 2ea

Speaker Management System

Loud Speaker Processor	L-ACOUSTICS	L-ACOUSTICS_Manager	1ea	Basic Tuning	
				Warning: Use only theater laptop for LA Manager	
Digital Processor	MEYER	Galileo_GALAXY_816	2ea	Fixed_(STAGE)	AVB => LS10(Network Swtich) => AMP

Microphone

Cable Microphone	SENNHEISER	MD427	5ea	
		MD421	3ea	
	SHURE	BETA58A	5ea	
		BETA56A	4ea	
		BETA52A	1ea	
		BETA87A	4ea	
		BETA98 H/C	4ea	
		SM81	2ea	
	AKG	451EB	4ea	
		C414B-TL2	2ea	
		D112	1ea	
	DPA	4011	2ea	
	CROWN	PCC160	4ea	
	OKTAVA	MK012	2ea	
	RODE	NT55	2ea	
	D.I BOX	AR133	4ea	

Wireless System

Antenna Distribution	SENNHEISER	ASA3000	1ea	Fixed_(STAGE)	
Receiver		EM6000_Dante(fre.470-698)	8ea	Fixed_(STAGE)	First Receiver_A_&_B_ch_Cascade
W/L Monitor System		MacBook with interface	1ea	Wavetool with Sennheiser WSM	
Antenna		AD3700(fre.470-698)	2ea		
Transmitter		SK6212(fre.550-638)	14ea	Bodypack Only (Lemo 3-Pin) / With battery 2Set	
		SKM6000(fre.550-638)	2ea	With battery 2Set	

Communication

Cable Communication	CLEAR-COM	SB440	1ea	Fixed_(SM_Desk)	Master Station
		RS601	6ea		Bodypack
		CC95	8ea		Headset
Radio Communication		FreeSpeak II-Base-II	1ea	Fixed_(SM_Desk)	Master Station
		FreeSpeak II 2.4GHz	5ea		Bodypack
		CC-110-x4	5ea		Headset