

■ YONKANG HALL SOUND EQUIPMENT

Local Power Supply

230 Volt Single Phase, 60Hz

Additional Power

Situated Upstage Left	32A X 2	16A X 2	(Legrand Type)
Situated Upstage Right	32A X 2	16A X 2	(Legrand Type)
Situated Stage Right	32A X 1	16A X 1	(Legrand Type)

Control Console

Main Console	DIGICO	SD10T	2ea	SD-Rack(96in/40out)
		(software version 10.5.1090)	(main)	SD-Rack mini(24in/8out)
			(redundant)	Aviom D-16, Dante

Speaker System

Main Left	L-ACOUSTICS	dv-DOSC / dv-SUB	10ea/2ea	Fixed LA8
Main Right		dv-DOSC / dv-SUB	10ea/2ea	
Center Speaker		KIVA	11ea	Fixed LA4
Sub Woofer		SB218	4ea	Fixed LA8
Under Balcony Speaker		5XT	8ea	Fixed LA4X
Front Fill Speaker		5XT	10ea	LA4
Monitor Speaker		MTD112	10ea	LA4X
		8XT	3ea	LA4X
Ceiling F/X Speaker	ALTO	15HA	6ea	Fixed
Surround Speaker	JBL	8330A	24ea	Fixed QSC CX254
Speaker	MEYER	MM-4	8ea	LA4
		MM-4XP	6ea	MPS-488

Speaker Management System

Loud Speaker Processor	L-ACOUSTICS	L-ACOUSTICS Manager	1ea	Basic Tuning
Digital Processor	MEYER	Galileo 616	1ea	

Microphone

Cable Microphone	SENNHEISER	MD427	5ea	
		MD421	3ea	
	SHURE	BETA58A	6ea	
		BETA56A	4ea	
		BETA52A	1ea	
		BETA87A	4ea	
		BETA98 H/C	4ea	
		SM81	2ea	
	AKG	451EB	4ea	
		C414B-TL2	2ea	
		D112	1ea	
	DPA	4011	2ea	
	CROWN	PCC160	4ea	
	OKTAVA	MK012	2ea	
	RODE	NT55	2ea	
	D.I BOX	AR133	4ea	

Wireless System

Antenna	SENNHEISER	AD3700(fre.470-866)	2ea	
Antenna Distribution		ASA3000	1ea	
Receiver		EM3732(fre.470-638)	6ea	
		EM3532(fre.678-714)	10ea	
Transmitter		SK5212(fre.470-638)	16ea	Bodypack Only (Lemo 3-Pin)
		SKM5200(fre.662-698)	4ea	capsule ME5005

Communication

Cable Communication	CLEAR-COM	SB440	1ea	Master Station (SM Desk)
		RS601	6ea	Bodypack
		CC95	8ea	Headset
FreeSpeak II-Base-II		1ea	Master Station (SM Desk)	
Radio Communication		FreeSpeak II 2.4GHz	5ea	Bodypack
		CC-110-x4	5ea	Headset

Projection System

LCD Projector	Panasonic	PT-DZ13KE /12000ANSI lens (ET-D75LE10,ET-D75LE20)	1ea	Fixed
---------------	-----------	--	-----	-------